

GYPROCK™

Everything else is just plasterboard

Jointing Gyprock™ Plasterboard

Shopping List

- Gyprock™ Paper Tape
- Gyprock™ Easy Tape for repairs and minor works
- Gyprock™ Pre-mixed Total Joint Cement or Multi-Purpose Joint Compound
- Curved trowels or broadknives 150mm, 200mm and 250mm
- Gyprock™ sanding float
- 150 grit sandpaper
- Dust mask
- Eye protection
- Gloves

Jointing



Jointing is the process of covering and reinforcing the joint between sheets to give a flush, seamless appearance. Paper Tape is bedded into the compound giving a stronger joint. Easy Tape is a self adhesive mesh that is stuck directly to the board and can be used where strength is not critical.

Recessed Joints

For recessed joints use a three coat system as follows.


Tape Coat

- 1 Fill recess in plasterboard evenly and fully with Gyprock™ Total Joint Cement or Multi-Purpose Joint Compound using a 150mm broadknife.
- 2 Bed in Gyprock™ Paper Tape centrally over the joint and cover lightly with compound.
- 3 Cover all fastener heads.
- 4 Allow to dry and harden for at least 24 hours, until the compound appears dry.



Second Coat

- 1 When the tape coat is dry, sand off any lumps and apply a second coat, about 170mm wide, finishing slightly above the board surface
- 2 Smooth the joint edges with a trowel to remove any lip to reduce sanding.
- 3 Cover fastener heads with a second coat of compound, laid in a different direction and extending beyond the first coat by about 25mm.
- 4 Allow to dry and harden for at least 24 hours.




GYPROCK™

Everything else is just plasterboard

Jointing Gyprock™ Plasterboard


Finishing Coat

- 1 When the second coat is dry, apply a thin finish coat over the previous coat, about 250mm wide.
- 2 Smooth the joint edges with a trowel to remove any lip to reduce sanding.
- 3 Cover previously coated fastener heads with a third coat of compound, laid in a different direction, extending beyond the previous coat by about 25mm.
- 4 Allow to dry and harden for at least 24 hours.




Sanding

- 1 Using the sandpaper and sanding float, carefully sand the joint to a smooth, even finish.
- 2 You will get best results by using a sanding float diagonally across the joint.
- 3 Avoid scuffing the paper face of the plasterboard where it meets the jointing cement.
- 4 Wear a dust mask, gloves and eye protection when sanding.



Butt Joints on Framing

- 1 At butt joints, use a three coat system as for recessed joints but extend the jointing to 250mm each side of the joint.



Using Gyprock™ Easy Tape

- 1 Remove any loose paint. Lightly sand and clean down painted surfaces where tape is to be applied.
- 2 Apply Easy Tape, sticky side down, directly to the surface.
- 3 Apply 3 coat system as described for paper tape.

For more information or to contact your nearest CSR Gyprock™ distributor call 1300 306 556 or visit www.gyprock.com.au

Your local stockist:

